



# *Progress with Bialkali Photocathode Development at SSL*

*Ossy Siegmund, Sharon Jelinsky, Jason  
McPhate, Joe Tedesco*


Experimental Astrophysics Group,  
Space Sciences Laboratory,  
U. California at Berkeley




# Biakali Cathode - Configurations

## Photocathode Operation Schemes

Bialkali is a few 100Å thick, and is nominally a deposition as a semitransparent layer on the window, with a proximity gap to the first MCP.



Nominal Cherenkov emission spectrum compared with bialkali









# Typical Bi-Alkali Cathode Characteristics

Lyashenko, Chicago 7/09



QE and resistivity for various bialkali's  
We will use  $\text{Na}_2\text{KSb}$  – **Why? Resistivity, noise, temperature robustness, uniformity.**

LAPPD Photocathode Godparent Review 7/10/2011




Cathode Noise vs Temp  
expect 10,000 to 40,000  
events/sec for 8" tube bialkali!



## Window of choice B33 - General Parameters


The cathode substrate, window or window coating, affects the photocathode performance. Borofloat B33 Borosilicate has been tested, and it is a good photocathode substrate. BUT - it has Tin diffused into one side, so we polish it. Anti-reflection coatings not baselined, (5 to 9% reflectance in bandpass).



Refractive index — @400nm

B33	1.47
Air	~1.0
Water	~1.32

### B33 Composition



**B33 Transmittance is typical of borosilicate glasses.**





# **Bialkali Cathode Development Program**

**Small window cathode development, 1.22" samples, 4 per run**

- **Processed samples to optimize QE and bandpass**
- **Studied  $\text{Na}_2\text{KSb}$ ,  $\text{K}_2\text{CsSb}$  cathodes**
- **Used several substrate materials,  $\text{SiO}_2$ , verified B33**
- **Tested MgO/ITO/conductor underlayer for cathodes**


**Large size window cathode study, 8.7" windows.**

- **Developed source alkali design for large cathodes**
- **Developed techniques to make larger area uniform QE**
- **Optimization of cathode QE levels successful**
- **No metal conductor under-layer is needed**
- **Use "X" conductor pattern matching tube hardware**
- **Testing window metalization and sealing techniques**



# Work Flow Program for Bialkali Cathode Development


We have run all the processes. Now we need to make the 20cm depositions in the large tube process tank.







## Tube Lab, 1.2" old sample test/process station.



**Small tank used to process alkali cathodes (33mm) and tubes of small area.  
Can take 4-8 samples/run. 7 runs done, more than 30 substrate coatings.**

- Small sample test runs
- Substrate material tests






# Bialkali Cathode Process Development Program

Small window cathode development, 1.22" samples  
- Processed samples to optimize QE and bandpass

**Window holder inside tank**



**Window holders and mask**




We cut up 8.7" B33 windows to make ~50 ea 1.22" test samples.  
Inconel annular electrodes were evaporated just as they would be for In seals





# Bialkali Photocathode Sample Tests

Cathode test runs with KCsSb and Na<sub>2</sub>KSb cathodes on borofloat-33 windows. Na<sub>2</sub>KSb ~25% QE achieved, QE uniformity better than  $\pm 15\%$ .



Bialkali test cathodes made on polished 31mm B33 windows gave the best results. Na<sub>2</sub>KSb measured hot, right after deposition, always improves after cool down. Have been able to repeat the process a number of times in different process tanks too.



# Small Cathode/Substrate Materials Summary

- ITO and MgO, 5nm are QE are not useful – poor QE
- No problems with inconel evaporated borders good adhesion/conduction
- $K_2CsSb$  cathode fabrication is problematic, lower temp tolerance, poor conductivity, more noise.
- B33 is a good substrate material
- Work with  $Na_2KSb$  as baseline, use Inconel conductor arranged on same “X” as support. B33 ok for rigorous cleaning, high temp, stable, uniform, high conductivity, good QE.





# 8" Cathode Process Development

## Large window cathode development, 8.7" square

- Commissioned 8" cathode/window seal process tank


### Objectives:-

- Copy small sample deposition method for verification
- Optimize alkali sources for large cathode areas
- Confirm 8" wet cleaning and plasma cleaning processes
- Test metal stripe underlayers for cathodes
- Optimize cathode QE levels and test stability and uniformity
- Trial window seals on 8.7" "frames"
- Next:-----
- Transfer techniques to large tube processing station



## 8.7" Photo-Cathode / Seal test Chamber


8.7" Square PC/seal test process chamber with 14" Dia. Capability 16.5" Dia. Chamber on same process cart as the previous chamber.



**Alkali sources**

**Larger 16" flange tank, for testing**


- Quantum efficiency
- QE Uniformity
- Seal tests








## 8.7" Photo-Cathode / Seal test Chamber



**Used SAES alkalis & SbPt beads. Employed old source flange to verify process, then we moved to new larger sources for next run.**


**Final assembly done, spent 3 weeks in initial cleanup bakeout up to 375°C to get the chamber conditioned.**








## Preparation of 8.7" B33 Windows for Cathodes



**NiCr electrode border on B33**

**All the tooling is in place. We have wet cleaned, plasma cleaned, and evaporated NiCr on a window, and loaded into the holder for photocathode processing.**




**Plasma cleaning**





## 8" Photocathode Processing & System Load




8.7" window loaded

- 8" PC/Seal Test Chamber
  - $<10^{-9}$  Torr base vacuum,
  - RGA operational, fully baked
- 5mm thick, 8.7" polished B33 window
  - NiCr border
  - electroded with "X" pattern
- Oxygen plasma clean,
- baked at 365°C for 16 hrs
- Used larger 40mm alkali sources.
- Deposited  $\text{Na}_2\text{KSb}$  photocathode
- RGA record for entire process
- Cathode everywhere
  - except extreme corners






# 8" $\text{Na}_2\text{KSb}$ Process #3A Preparations



**Bakeout**



**Alkali Outgas**



# Photocathode Deposition Outgassing



K Sb


Na

K Sb






# 8" Na<sub>2</sub>KSb Process #3A



**Cathode Shoot Outgassing**




**Alkali / Sb sources in action**





# 8" -Na<sub>2</sub>KSb Bialkali Processing




#3 is a redder cathode than before, but we made this one much thicker which can be seen in the opacity of the cathode. We get a typical enhancement of the QE after cool-down. The QE remained stable over the 5 days after deposition. This is not corrected for the 5mm thick window transmission which we expect to be about 85%. Average PMT cathodes of this type peak at about 18% so we are above that.



## 8" $\text{Na}_2\text{KSb}$ Process #3A

No  
Cathode

Cathode



Window (hot) was lifted after process to  
simulate an indium hot seal procedure


"X" electrode






# 8in #3A Photocathode Uniformity

Majority of the area is within  $\pm 15\%$  of the average QE, There is some obscuration by tooling in some places.






## 20cm - Na<sub>2</sub>KSb Bialkali on Borofloat 33



Basic process is a co-evap technique. We get an enhancement of the QE after cool-down. The QE has remained stable over the 2 months since deposition.

Smaller 31mm windows give similar results (deposited in different process tank)







# 20cm PhotoCathode Test Chamber & Sealed Tube Device Process Tank

**Process Tank Now In Conditioning Bake**



LAPPD Photocathode Godparent Review 7/10/2011

**Sealed Tube Device Process Tank**  
MCP conditioning, photocathode process and transfer seal.





# 20cm PhotoCathode Progress Summary

- 8" PC/Seal Test Chamber
  - $<10^{-9}$  Torr base vacuum, RGA operational, fully baked
- 8" Sealed Tube Process Tank
  - $<10^{-9}$  Torr base vacuum, RGA operational, will complete bake-out commissioning this week
- 5mm thick, 8.7" polished B33 window, NiCr border with "X"
- Deposited  $\text{Na}_2\text{KSb}$  photocathodes on 8" windows
  - Get comparable results to small sample windows
  - ~25% with good uniformity and stability meets our needs
  - Can repeat successful process in different vacuum tanks with different hardware
- RGA/pressure/temp/response record for entire process