

# Demonstration of the 8" window-to-body seal solution

O.H.W. Siegmund,

Experimental Astrophysics Group,
Space Sciences Laboratory,
U. California at Berkeley



# **LAPPD 8" Window to Body Seal**

- UCB uses Alumina body construction with hot indium seal onto borosilicate window.
- Variety of window material options, Schott B33, B270, D263, need to be metalized to get good Indium adhesion
- Alumina frame is paired with a Kovar/Ni/Cu plated Indium well that are H<sub>2</sub> brazed together to form the detector body
- Initial trials can be done with a "sheet" of Alumina rather than an alumina "window frame" so that the missing "anode" does not cause fragility/warping stresses.



# Schott B270/D263 General Parameters

The cathode substrate, window or window coating, changes the photocathode performance. Quartz, fiber optics, 7056 glass are common. Borosilicate is not, so we need to test this.

B 270 Superwite is a clear high transmission crown glass (modified soda-lime glass) (85% transmission at 340nm for 2.0mm) Coefficient of Thermal Expansion (Static Measurement, 20-400° C.) 9.6 x 10-6 °K

D 263 is a borosilicate glass (85% transmission at 380nm for 2.0mm) Coefficient of Thermal Expansion (Static Measurement, 20-300° C.) 7.2 x 10<sup>-6</sup> °K

### Refractive index

@400nm

D263 1.52

B270 1.53

Air ~1.0

Water ~1.32

B33 borofloat is contaminated with Tin on both sides, although otherwise appropriate, may need an inconvenient polish operation before use.



# **Brazed Body Development**


Indium well is filled with a eutectic Indium alloy & vacuum baked/cleaned to remove oxides.

8.7" "Window frame" construction. Body design has machined alumina frame (cut from sheet) which is H<sub>2</sub> brazed to a Kovar indium well (Ni and Cu plated) and to the anode. Window seal tests can use a sheet of alumina instead of the frame, with spacers to accommodate vacuum leak tests.



## **Window Seal Development**


Will metalize 8.7" window and produce an Indium seal on a test article to test leak tightness of the seal.



3" window test article on metal frame with Indium seal



## **Window Seal Development Process**






## Window and Cathode Process Test Tank System



Same size scale



Small tank is used to process alkali cathodes (33mm) and tubes of small area.

Can take 4-6 samples/run

- Small sample test runs
- Substrate material tests

Larger flange tank, 16.5"
Can take big windows to test

- -Seal tests
- -Window manipulation
- -Some room to move inside!



## 8" Tube Seal and Cathode Process Tank System



UHV 16.5" process tank for cathode and seal development with B270/D263 8.66" windows:-

- large area cathodes
- uniformity tests
- QE optimization





## Tube Lab, oven and test/process stations.

#### **Process Oven**



LAPPD Cathode Godparent Review 3/3/2010

#### Plasma cleaner



Leak Checker





**Evaporator** 



#### 8" Tube Seal Test Status

## Large window seal development, 8.66" square

- Facilities, have everything except larger UHV tank
  - Need to commission plasma cleaner
  - UHV tank coming, need to prep & install on current stand
- Windows, have B270, need to get D263
  - Need tooling for metalization scheme
  - Need tooling for window manipulation
- 8.66" detector "bodies"
  - Have design for In well, quote coming
  - Have quote for alumina sheets/frames
  - Getting quote for materials prep and brazing