



ARRADIANCE®

Status

ALD Secondary Electron Emission Program

Delivered to PSEC Collaboration Meeting

Neal Sullivan

October 15, 2009

- ◆ Status and Summary of Contract
- ◆ Progress on MCP ALD equipment
- ◆ Progress on MCP Emissive film performance
- ◆ Progress on MCP Resistive film performance
- ◆ New MCP Application: Special Nuclear Material Detection – Fast Neutron Detector
 - ◆ Plastic MCP ALD films development
 - ◆ Fast Neutron Detection Simulation development
 - ◆ Plastic MCP performance
 - ◆ Neutron Detection Experimental Results
 - ◆ University of New Hampshire (UNH)
 - ◆ Massachusetts Institute of Technology (MIT)
- ◆ Summary



1 Year Contract No. 9F-32341 (Oct 1, 2009): \$120,434.00

- ◆ **Objective:** Optimize Arradiance thin film technology process & process equipment to meet performance requirements for LAPR-TOF glass and small sample AAO substrate development.
- ◆ Work Plan Detail (Glass and AAO substrates):
 - ◆ MCP manufacturing & performance requirements definition: Inputs from program & Arradiance simulation driven film parameter determination
 - ◆ Film optimization on 33 mm capillary glass substrates: resistance and emission optimization; process integration and functionality
- ◆ Work Plan Deliverables:
 - ◆ Development of ALD emissive & resistive films which meet gain, resistance & uniformity specifications on glass & AAO substrates.
 - ◆ Process and test of up to 20 capillary glass and 20 AAO functionalized prototype MCPs.
 - ◆ Proof of Principle Report to the project
- ◆ **Status:** Awaiting funding for ALD and Test fixture build to accommodate 33mm samples

Arradiance GEM ALD Equipment – 2nd Generation MCP ALD processing

Three stage precursor heating prevents unwanted condensation

Compact (23"x26") footprint

Up to 4 precursors

Compact chamber for efficient processing



Powerful built-in CPU standard in base unit

Chamber door pulls out for easy load and unload of door-mounted substrate holder.

Easy to reach batch boat design to hold up to twenty-five 1" diameter MCP substrates.

Larger dia substrates (up to 76mm) can be loaded in smaller quantities.



Holder positions substrates such that all substrates see uniform gas flow over entire surface area.








Uniformity for MCPs: High Aspect Ratio & High Surface Area

- ◀ Separate gas delivery lines to avoid precursor mixing and contamination.
- ◀ Showerhead precursor delivery isolates & distributes uniform gas flow to all MCP substrates.
- ◀ Convective, rather than conductive, heating assures uniform temperature across reaction chamber.
- ◀ Chamber geometry accommodates MCP structures with uniform heating and gas flow.
- ◀ Minimum chamber volume for faster heating, cool-down, pumping times and minimal precursor usage.
- ◀ Chamber geometry designed for optimum pressure control.




Commercial GEM-D2 Application I

- Commercial MCP base resistance of $\sim 100\text{M}\Omega$ at 1000V.
- Increased SEY of GEM-D2 film
- Short term scrub, extracting 0.02 C at $I_{\text{out}}=0.3\mu\text{A}$ (14 hrs), did not degrade gain.



Commercial GEM-D2 Application II: CASCADE First Order Gain (FOG) Analysis

- Before and After GEM-D2 Emissive Coating
- 60:1 LD 12um Pitch 12 Degree Bias



Change Model with Yellow Columns

9/23/2009

Does not include tilt angle, Pore Dia, I/O Field, Charging effects

Changeable Parameters	FOG 1	FOG 2	FOG 2/FOG 1	Description
	0.6	0.6	1.00	Open Area Ratio
	5	7	1.40	SEY Constant (First Impact)
	0.5	0.5	1.00	End Spoiling in Diameters
	60	62	1.03	L/D Ratio
	1.04	1.35	1.30	SEY Constant (Relative to D2)
	12	12	1.00	Bias Angle (Degrees)
	120	100	0.83	MCP R (MΩ)
	6.55	5.28	0.81	Input I(pA)
	8.0%	8.0%	1.00	SAT Coefficient (% Strip)


FOG Analysis Results For GEM-D2

- 40% increase in first strike SEY
- 30% increase in pore cascade SEY
- 3 % increase in apparent LD ratio

FOG Model results fitting measured before and after GEM-D2 data (Solid line is modeled)


R2D2 Lot to Lot Repeatability

40:1 LD 10 um Pore Micro Channel Substrate



SNM detection technology overview

- ◆ Hydrogen-rich PMMA microchannel structure
- ◆ Graded Temperature ALD deposition
 - ◆ Active films deposition at 140C
- ◆ Neutron-proton recoil reaction within plastic at better than 1% efficiency
- ◆ Proton initiated secondary electron cascade
- ◆ Output pulse $10^3 - 10^6$ electrons
- ◆ Standard readout electronics
- ◆ Technology is scalable to large format



Summer 2009 Experimental Data Collected

Prof. Jim Ryan UNH - Space Science Center

- 06/04/2009
- PMMA, 2mm, > 40k
50um Pores, 20um wall

Isotope sources: Cf-252 (n, γ), Am-241/Be (n, γ), Cs-137 (γ), Co-60 (γ), Am-241 (γ)

Results

$$\gamma \text{ QE} = 8.85\text{E-}04$$

$$n \text{ QE} = 3.28\text{E-}03$$




Dr. Dick Lanza MIT - Nuclear Science & Eng.

- 08/19/2009
- PMMA, 5mm, > 40k
50um Pores, 20um wall,

Thermo Scientific 300 series D-T source (14MeV - pulsed)

Results

- nQE \sim 1.2%
- Source limited $t < 1.5 \text{ us}$
- dark count $\sim 0.3 \text{ c/cm}^2/\text{s}$





P₁ – n-p recoil within the MCP substrate


P_2 – proton escape into MCP pore

P₃ – electron avalanche is formed (MCP ~1)

$$P_1 = 1 - \exp(-N_H \sigma_n L_{eff})$$

$$L_{\text{eff}} = L_{\text{eff}}(x_0, y_0, \theta, \varphi)$$

$$N_x = 2 \frac{\rho_{MCP} m_x \mu_x}{M_x \sum_i m_i \mu_i}$$




$$S_i(x_0, y_0) < R(E_p(\theta))$$

$$S_i(x_0, y_0) = \frac{\sqrt{(x_1 - x_0)^2 + (y_1 - y_0)^2}}{\sin(\theta)}; \theta \neq 0, \pi$$

$$(\mathbf{x}_1 - \mathbf{x}_0)^2 = \left[\min \left\{ -\left(t\mathbf{g}(\varphi) \cdot \xi - 0_{i,x} \right) \pm \sqrt{D} \right\} \cos^2(\varphi) - x_0 \right]^2 \quad \xi = y_0 - t\mathbf{g}(\varphi)x_0 - O_{i,y}$$

$$y_1 = \operatorname{tg}(\varphi) \cdot x_1 + (y_0 - \operatorname{tg}(\varphi)x_0)$$



$$\cos(\theta) = \sqrt{\frac{E_f}{E_n}}$$

$$E_p \in [0, E_n]$$

$$D = (tg(\varphi) \cdot \xi - O_{i,x})^2 - \left(O_{i,x} + \xi^2 - \frac{d^2}{4}\right)^2 \frac{1}{\cos^2(\varphi)}$$

Neutron detection simulation: proton recoil - P1

PMMA ($\text{C}_5\text{-O}_2\text{-H}_8$)_n

monomers / cm³ 7.16x10²¹



H atoms / cm³ 5.73x10²²

C atoms / cm³ 3.58x10²²

O atoms / cm³ 1.43x10²²

Cross section of neutron interaction

$$P = [1 - \exp(-N_i \sigma_i L)](1-A)$$



50 μm circular pores, 20 μm walls, 1.19 g/cm³



Neutron detection simulation results – P1 and P2


$$P_{\text{detection}} = P_1 * P_2 * P_3$$

P_1 – n-p recoil within the MCP substrate


P_2 – proton escape into MCP pore

P_3 – electron avalanche is formed (MCP ~1)





P1



P2



P1*P2*P3



Neutron detection simulation: P3 Probability and Event Timing Simulation



Neutron Detection Stage



Signal Amplification Stage

Note:

P3 – Probability for Amplification Stage is 1.0

Timing for Amplification Stage is < 200 ps

Operating at 1200V Bias (Average Gain 47)
P3 - Probability 0.9 for 100:1 LD 50 um Pores




For 99.9% of events, we should expect a pulse timing uncertainty in coincidence mode of operation of ± 1.5 ns

For 90% of events, we should expect a pulse timing uncertainty in coincidence mode of operation of $< \pm 1.0$ ns




UNH Experimental Summary





γ isotopic sources

Gamma E (eV)	QE
4.00E+04	9.26E-05
6.61E+05	2.06E-03
1.20E+06	5.22E-03



Pulse source: timing performance MIT measurements with a pulsed source

Predicted QE $\sim 0.8\%$






Conclusions:

1. QE to 14 MeV neutrons is $\sim 1.2\%$
2. n and γ counts are comparable at this source settings
3. Timing better than $1.5 \mu\text{s}$ (measurement limited by the source)
4. MCP dark count very low ($\sim 0.3 \text{ c/cm}^2/\text{s}$)

Hardware Experimental setup

- 5 mm PMMA MCP, ~50 μm pores, 20 μm walls, 5° bias angle
- installed above a chevron stack of 50:1 L/D MCPs
- Phosphor screen readout
- Canberra preamp and postamplifier





Summary

- ◆ Contract signed – Await funding release
- ◆ 2nd Generation ALD Process Equipment ready for PSEC MCP substrates
- ◆ Simulation support for SE yield determination from MCP measurements is complete.
- ◆ High performance MCP active film results demonstrate success
 - ◆ High secondary electron yield results in high gain MCPs
 - ◆ Targeted and Repeatable MCP device resistance
- ◆ Novel MCP application demonstrated: Fast neutron detector, implemented in high H plastic substrate, with low noise and high efficiency demonstrated
 - ◆ ~1% Neutron detection efficiency target
 - ◆ < 0.1% Gamma detection efficiency
 - ◆ < 0.3 C/s-cm² Noise