

Future Plans for Photocathode Studies

Junqi Xie, Marcel Demarteau, Ed May, Sasha Paramonov, Bob Wagner, Zikri Yusof

**LAPPD Collaboration
High Energy Physics Division
Argonne National Laboratory
Tuesday, July 10th, 2012**

Burle System


- Continue to refine the recipe for large area photocathode
 - finalize the RF plasma setup
 - test the thickness uniformity after place the Sb beads further apart.
 - investigate the affect of plasma cleaning and oxidation
 - test additional cathode properties
 - Aging
 - Dark Current
- Study variation of QE verse Sb thickness
 - use 1 Sb bead deposition to obtain a variety of Sb thicknesses
 - complete absolute reflection measurement of Sb films and relate to the film transmission data. --- Calibration
 - use elliposometry measurement to obtain absolute thickness of Sb film, relate the transmission/reflection data with Sb film.



UHV-System

- Current Status

- Retractable arm was installed
- RGA was installed
- Quartz crystal microbalance was installed.



UHV-System

- Future plans

- Complete necessary instrumentation for the UHV system.
 - water cooler for the quartz crystal microbalance
 - IR camera for the source temperature measurement
- Study the evaporation process for Sb bead and K, Cs dispensers.
 - Evaporation temperature of the sources
 - Gas species during evaporation
 - Sb film growth rate
 - Compare the Sb thickness values from QCM with the values from UV-Vis measurement
- Study the cathode growth recipe step by step
 - Sb film growth rate
 - Sb film resistivity change, phase transition
 - In-situ monitor the film property (optical and electrical) as the K and Cs deposited
 - Transfer the knowledge to burle equipment for recipe refinement.



Instrumentation (Henry suggested)

- Can we record important parameter time to time?

Parameters need to be recorded:

- Temperature
- Pressure
- Source bias-voltage and current
- RGA species
- Reflectivity during Sb deposition
- Photo-current during K and Cs deposition
- Other parameters?...




Instrumentation (Henry suggested)

Reflectivity during Sb deposition

Temperature,
pressure

Photo- current during
K and Cs deposition



Central
computer

RGA

Detector
head is too
far away
from sources



Bias-voltage and current

Blue color, program available, can be recorded

Red color, no program, need electronic integration

