

AAO Based MCPs for Large Area Photo-Detectors

Seon W. Lee† and H. Hau Wang‡
High Energy Physics Division †, Materials Science
Division ‡
Argonne National Laboratory
Godparent Review October 4th, 2010

Contents


- **What is anodized aluminum oxide (AAO)?**
- **Advantage of AAO based MCPs**
- **Roadmap for the Development of AAO based MCPs**
- **Recent progress**
 - Improved procedure for better micro-machined pores
 - Controllable funnel-shaped entrance formation
 - Large open area (78%) demonstrated



What is AAO?



Nanoporous material consists of self-organized hexagonally closed packed nano-scale pores formed by anodizing aluminium

Intrinsic pore



3-D model of AAO

http://www2.chem.umd.edu/Groups/slee/new_site/research.html




<http://terpconnect.umd.edu/~pban/research.htm>
Cross-section of AAO

Atomic Force Microscopy (AFM) image on top of AAO


Advantage of AAO based MCPs

1. Al is inexpensive
2. Pore diameter can be varied in a wide range :
 - intrinsic pores (20 ~ 500 nm) through anodization
 - micro-machined pores (500 nm – 40 μm) through lithography and etching
 - 32.8 mm – laser writer, 8"X8" Large scale – photomask +




Advantage of AAO based MCP


3. Intrinsic pores help to create vertical channels through wet



Cross-section of Etched Pores




Intrinsic pores 50 nm



Si etching: not possible to etch deep trench with high aspect ratio

- 4. Funnel-shaped entrance can be fabricated
- Intrinsic pores have naturally funnel-shaped entrance
- Funnel-shaped entrance is feasible through etching



Roadmap for the development of AAO based MCPs

**Develop fabrication process
to create micromachined pores**



**Optimize L/D for max. gain:
by varying AAO thickness (L) and micromachined pore
diameter (D)
Large open area ratio**



**Build funnel-shaped channel entrance
ALD coating to enhance secondary electron emission**




Testing and scale up to 8" X 8" tile



2 μ m, 5 μ m, 10 μ m hcp (hexagonal closed packed) pores patterns







- Diameters of pores and pore-to-pore distance can be varied by drawing pattern







Optimize L/D to maximize gain

- a. Electron multiplication is determined by channel aspect ratio Length to Diameter (L/D).
- b. Maximize open area ratio



Thickness of AAO controlled through time and voltage




Lee et al. Nat Materials, vol 5, p741 (2006)

Aspect ratio


- Required AAO thickness (in μm) to meet the aspect ratio (L/D)
- White areas are straight forward

Aspect ratio L/D	Pore size D, μm	1 μ	2 μ	5 μ	10 μ	20 μ
40	20 μm	40 μm	80 μm	200	400	800
60	30 μm	60 μm	120	300	600	1200
80	40 μm	80 μm	160	400	800	1600
100	50 μm	100	200	500	1000	2000

Long anodization time in
sulfuric acid leads to
damage



Open area





Pore size hcp structure $a = \text{pore}$	Pore-to-pore distance	Calculated open ratio	Accomplishment
a	$2 a$	22.7 %	Accomplished (2/2010)
a	$1.5 a$	40 %	Accomplished for small area test sample
a	$1.25 a$	58 %	Accomplished for small area test sample
a	$1.10 a$	78.7 %	Demonstrated (7/2010)
a	a	90.7%	Possible only with



- Open area up to 80% is feasible.
- 90% open area is only possible if funnel shaped entrance can be prepared.



Status of testable AAO based MCP at Argonne




- 32.8 mm free standing AAO
- Pore size : 20 μm
- Open area ratio : 22.66%
- L/D : 10



Optical image: Front 10X Back 20X

SEM images - AAO with etched pores




Challenges in AAO etching


- 1. General difficulty
 - Optical imaging is not sufficient to determine the degree of etching
 - SEM imaging is required to follow the process
- 2. Uneven etching –
 - The Al surface should be as smooth and even as possible
 - Avoid AAO surface contamination (hydrophilic vs. hydrophobic areas)
 - Stirring of the etching solution
- 3. Alumina nanowires hanging inside the patterned pores
 - Mild sonication helps to remove these nanowires
- 4. Slight over-etching creates the desired funnel-shaped entrance
 - Timing is very critical
 - Over-etching will destroy the membrane
- 5. Open area can be controlled through etching
 - Timing is very critical




Effect of sonication - clean up pores



AAO after etching - back side




Back side - after sonication



AAO after etching - front side, showing

Al_2O_3 nanowires inside the pores





Back side - after sonication

12 μ
pores





Funnel-shaped entrances through etching



Shallow
funnel angle


AAO membrane with 10 μm pores – slightly over-etched



Much deeper
funnel angle

AAO membrane with 15 μm pores – more over-etched





Open area ~78% is demonstrated



AAO membrane with 18 μm pores and 78% open area



5 μm pore photomask ($15 \times 15 \text{ mm}^2$) is prepared



Photomask with 5.0 μm pores is ready
AFM image (left) and depth profile (right)

Summary and Future direction

- AAO based MCPs with 20- to 10- μm micro-machined pores have been developed.
- The following challenges have been overcome:
 - a) Loose alumina nanowires in the micro-machined pores
 - Removal through sonication
 - b) Controllable funnel-shaped pore entrance – demonstrated
 - c) Open area up to 78% – demonstrated
- 5 μm pore photomask is ready for photo-lithography
- Working with the ALD group for secondary electron emission coating, avoid sample bending, ..etc.
- Working with the characterization and laser testing groups on ALD/AAO/MCPs
- ~~Year 1 milestones:~~ **Scale up to 8x8" samples**
 - (a) Achieve straight pores in AAO with diameter 0.7 microns (no-funnel option), $40 < L/D < 100$, and open-area ratio 60 %;
 - (b) Demonstrate the feasibility of making AAO funnels suitable for photo-cathode deposition;
 - (c) Produce blanks of 32.8mm AAO plate for tests and MCP development.
 - (d) Evaluate the process economics.



Detector applications suitable for AAO based MCPs?

Pro / AAO strength

- Small pores (30–350 nm intrinsic pores) are readily available that are not feasible with glass fibers
- Larger pores (500 nm – 40 μm) can be fabricated
- Special requirement such as funnel-shaped entrance can be fabricated
- Small pores may provide faster timing and spatial resolution

Con

- Chemical etching requires extensive optimization
- Porous alumina is not as strong as glass
- Membrane thicker than 500 μm is hard to make

