


# Large Area Picosecond Microchannel Plate Photodetectors

Bob Wagner  
Argonne HEP Division  
Tuesday 04 Sept 2012  
for the LAPPD Collaboration

# Motivation – Pushing the Limits of Time Resolution

- Project evolved from LDRD to improve Particle ID in colliding beam experiments




**Goal:** Measure ALL information  
ID quarks producing the jets.  
Need particle ID for momentum  
of 10's of GeV/c

Complete particle measurement: E, p + **m(PID)**  
1ps time & 1mm space resolution

# Applications – Tracking Neutrino Water Cherenkov Detector


**Technique:** measure arrival time and position of photons and reconstruct tracks in water



← Tessellation of detector with Large Area MCP-PMTs

Results of a toy Monte Carlo with perfect resolution

Color scale shows the likelihood that light on the Cherenkov ring came from a particular point in space. Concentration of red and yellow pixels cluster around likely tracks



graphic credit: Matt Wetstein

# Applications – Photon Vertexing

## Rare Kaon Decays - $K_L \rightarrow \pi^0 \nu \bar{\nu}$

Combination with precision energy resolution in calorimeter critical

**Vertex  $\pi^0 \rightarrow \gamma\gamma$**   
 $T_v, X_v, Y_v, Z_v$

**Photon 1**


$T_1, X_1, Y_1$

**Photon 2**

$T_2, X_2, Y_2$

One can reconstruct  
the vertex from the  
times and positions-  
3D reconstruction


MCP – based EM Sampling Calorimeter



Reduce combinatoric background for  $\pi^0$



# Microchannel Plate Photomultipliers



## Existing commercial MCP-PMTs:

- Fabrication constrained by common material for substrate, resistive and emission layers
- $\leq \sim 25\text{mm}^2$  active area
- Expensive


## Components of the Large Area Picosecond Photodetector Development:

- Transformational improvement of MCP fabrication and size
  - 8"×8" borosilicate glass w/20&40 $\mu$ m pore
  - Resistive & secondary emissive functions separated into 2 materials via ALD coating
- Development of planar, large-area photocathodes
- Waveform sampling 10GSa/s electronics readout
- Development of economical hermetic packaging
  - Standard ceramic package w/InBi hot seal & HV/signal pins feedthru — [SSL/UC-Berkeley](#)
  - Inexpensive borosilicate all-glass w/thermopressure seal, pinless — [Argonne/UChicago](#)




# Development of Economical Borosilicate Capillary Arrays for MCPs – Industrial Partnership w/Incom, Inc

First block 2010



- Multifiber stacking
- Triple point gaps
- Pore crushing at multifiber boundaries

Most recent block 2012




- Triple points mostly eliminated
- Minimal boundary pore distortion

**Capillary array quality dramatically improved during last 2.5 years**

**Future: Continued fusion and finish quality improvement, reduce pore size, larger L/D, reduce production cost**




# ALD Materials Development




3 Resistive Chemistries invented by ANL ALD Group:

- Tunable R over 6+ orders of mag.
- R vs. Temp. stable against thermal runaway
- Functionalized MCPs exhibit high gain

$G=4 \times 10^6$  @ 1000V



Pulse height amplitude distributions. MCP pair, 20 $\mu$ m pores, 8 $^\circ$  bias, 60:1 L/d, 0.7mm pair gap with 300V bias. 3000 sec background.



ALD development: Anil Mane & Jeff Elam, Argonne ESD

graphic: Ossy Siegmund, SSL


DOE Site Visit, 04 Sept 2012, Bob Wagner, Argonne HEPD




# MCP Development & Testing

## MCP Lifetest:

350°C bakeout then 1-3 $\mu$ A “burn-in” to 7C/cm<sup>2</sup>




Gain curves of 33mm ALD MCP pair during conditioning.



UV illumination of ALD MCP pair compared with conventional MCPs.

## Background Noise Measurement (separate from lifetest)



0.0845 events/cm<sup>2</sup>-s  
7 x 10<sup>6</sup> gain

Rate comparable  
to cosmic bkgd

## Desirable MCP properties with MgO SEE:

- No precipitous initial gain decrease as seen in commercial MCPs.
- Little or no aging up to 7C/cm<sup>2</sup>.
- MgO SEE produces low-noise MCP

graphics: Ossy Siegmund & Jason McPhate, SSL

# MCP Development — Scaling to Large Area



Beneq reactor & clean room enclosure purchased jointly with Argonne ESD

## 8" MCP Pair test at SSL




Top MCP  
Bias direction



Bottom MCP  
Bias direction



1. Routinely producing targeted resistance
2. Emphasis now on SEE layer gain uniformity





## Areas of Future Focus for MCP Development

- **Near term:**
  - Tune ALD processing for uniform gain
  - Produce 8" functionalized plates for sealed detectors
- **3 Year Plans:**
  - Explore new ALD chemistries for lower cost, higher rate
  - Refine ALD coating for higher throughput
  - ALD functionalization technology transfer to industry



# Photocathode Development – Argonne



Sb beads

K, Cs  
dispensers


21-pin  
connector for  
beads,  
dispenser,  
signal wiring

Large glass vacuum vessel  
(**Chalice**) replaced small PMT  
manifold to produce 4" & 7"  
photocathodes

Learned photocathode fabrication techniques on  
phototube process system purchased from Burle

**Developing techniques to scale  
to 8" transfer cathode for Tile  
Facility at Argonne**


# Scale-up to 7" Photocathodes at Argonne



13 Photocathode shoots on "erasable" glass window:


- Tune process parameters
- Optimal # and placement of Sb, K, Cs dispensers
- Improve QE and uniformity

QE Map



Chalice Photocathode #9

KCs-Sb Photocathode




Optimization of QE w.r.t SB thickness  
% transmission of Sb  $\Rightarrow$  thickness

- Photocathode fabrication established at Argonne
- Ongoing study for uniformity and QE>20%
- **Future:**
  - transfer techniques from Chalice to 8" tube processing system at Argonne
  - Collaboration with SSL, BNL, UChicago, WashU, ... on understanding and improving photocathode QE




# Development & Testing of Front-end Electronics




**PSEC4 6-ch.**  
**“scope-on-a-chip”**  
**1.6 GHz BW, 10-15 GSa/s,**  
**130nm technology**

PSEC ASIC Design and Testing by  
 Univ. of Chicago & Univ. of Hawaii




Evaluation board w/2.0 USB  
 interface + PC DAQ software

**Noise**




**DC Response**



- Low noise <1 mV
- ~1V dynamic range with excellent linearity
- Analog bandwidth of 1.6 GHz
- Sampling rates up to 15 GSa/s


**Frequency Response**



PSEC 4 design & test results: Eric Oberla  
 & Hervé Grabas, Chicago




# Glass MCP Phototube Strip Line Anode




Tile base is 30 strip silk-screened anode

- One 8" MCP Glass PMT  $\equiv$  Tile
- Serial connection of tiles with common double-end readout minimally affects performance
- 4 $\times$ 3 array of tiles  $\equiv$  SuperModule Tray
- Complete readout chain from front-end waveform sampling ASIC through digital and central control cards to graphics processor PC has been integrated into SuperModule



Digital & Central DAQ Boards: Mircea Bogadan & Craig Harabedian, Chicago


## Tray and Tiles — The Super Module System






# Strip Line Anode Performance with 8" MCP Pairs


## Single PE Time Resolution



## Position scan along stripline w/double-ended readout




## Differential Time Resolution vs. Noise




- ▶ Results from Argonne 8" Test Ch. w/UV laser excitation, fast scope readout (M.Wetstein, B. Adams, A. Elagin, R. Obaid, A. Vostrikov)
- ▶ Un-optimized Anode performance impressive and meets present needs
- ▶ Prospects for improvement to few ps resolution are good



# Development of Hermetic Package – All Glass Tile



Design Drawing - September 2010




Realization in Demountable

## Demountable is o-ring sealed tile:

- Continuously pumped sealed tile with 8" MCP pair
- Al photocathode on quartz window
- ALD grid spacer for HV distribution
- 30-strip anode to fanout board

## Future Work:

- Complete work presently ongoing for Indium pressure seal for top window
- Produce smaller format sealed tiles in existing vacuum transfer system
- Produce sealed tiles with bialkali PC in future Argonne Single Tile Processing System





# Development of Hermetic Packaging – Ceramic Tube



- ▶ Process tank in commissioning
  - readying for 1<sup>st</sup> photocathode shoot in process tank; several 8" done in separate test chamber
- ▶ In/Bi seal tests in 8" test chamber
- ▶ Tile base braze progressing; ready for 3<sup>rd</sup>/final iteration
- ▶ On track for sealed tube this Fall

# LAPPD Future Directions

- ▶ **SBIR/STTR:** At least 5 Letters of Intent from industry for 2013 FOA
  - Fully integrated sealed detector devices – STTR
  - MCPs for improved spatial/time resolution
  - Theory-based high QE photocathode development
  - Non-vacuum transfer process for production of MCP-PMTs
  - PET camera development
- ▶ **Tasks Requested for KA15 funding:**
  - All-Glass Tile Fabrication at Argonne (eventually several 10s per year)
    - Small format (<4” sq.) with modification of existing vacuum transfer system
    - 8” Single Tile Processing System
    - **Rationale: Glass tubes for distribution to HEP community; MCP, ALD, photocathode development testing, alternative formats**
  - Ceramic Tile Fabrication at SSL (5–6 per year)
    - Improve design and throughput
    - Improved QE
    - All-glass fabrication in SSL process tank
  - Generation II R&D (Argonne, UChicago, SSL, UHawaii)
    - Improved MCPs, photocathode, readout



# Existing 4" Vacuum Transfer System at Argonne – System for Early Vetting of STF Process



Two chamber CsTe Photocathode Transfer System



Indium Top Seal Vacuum Test Chamber

## Possible early STF demonstrator:

- Chambers can be coupled via existing 6" flanges to give PC process chamber and sealing chamber.
- Left system is operating now at  $5 \times 10^{-10}$  torr, right system is  $10^{-8}$  torr
- Photocathode Transfer System will be moved to Bldg. 360 in September

# LAPPD Project Summary

## Capability Gap

- Existing MCPs have small effective area, are expensive, and have all properties embodied in a single medium.
- Development of large area MCP-PMTs with few ps resolution would provide a transformational tool for HEP experiments, e.g.
  - Water Č tracking detector
  - Higher momentum Particle ID
  - Pile-up vertex separation/Photon vertexing

## Benefit

- Potential for picosecond time and millimeter spatial resolution photodetection over large surface areas.
- Applications within and beyond HEP.
- Re-establish U.S. photodetector development and manufacturing.
- Potential large cost savings for detectors requiring 1000s of photodetectors.

## Approach

- MCP substrate, resistive, and emissive components separated into individually tunable materials.
- Less expensive borosilicate glass hermetic package
- Parallel ceramic body approach using proven techniques and expertise.
- Integrated DAQ w/Waveform Sampling ASIC frontend.
- Enabled by unique multi-disciplinary expertise and cross-divisional infrastructure at Argonne

## Results and Future

- Signals from o-ring sealed complete all-glass MCP tile
- Diff. time resolution with 8" MCP pair < 6ps
- Complete DAQ system with PSEC4 ASIC; 15 GSa/s; noise<1mV, bandwidth ~1.6GHz
- 8" Photocathode QE~25% @ 350nm & uniform & stable
- On track for sealed ceramic MCP-PMT by Fall
- Propose to construct MCP Tile Facility at Argonne to produce all-glass tiles for evaluation by HEP community
- Continue production of ceramic tiles at SSL
- PC research to achieve QE » 25%
- Seek industrialization of photodetector through SBIR/STTR



# Backup Slides



# The Large Area Picosecond Photodetector

## Participants During the First 3 Years

### ▶ National Labs

- Argonne
  - HEP Division
  - Energy Systems Division
  - Nuclear Engineering Division
  - Glass Shop
  - X-ray Sciences Division
  - Materials Science Division
  - Mathematics and Computer Science Division
- Fermilab

### ▶ Universities

- University of Chicago
- Space Sciences Lab/UC–Berkeley
- University of Hawaii
- Washington University
- University of Illinois — Chicago
- University of Illinois — Urbana/Champaign

### ▶ U.S. Companies


- Incom, Inc.
- Arradance, Inc.
- Synkera Technologies, Inc.
- Minotech, Inc.
- Muons, Inc.

LAPPD is a multi-disciplinary/multi-institutional effort that draws on the unique expertise and infrastructure at Argonne and at our partner institutions




# Development of Economical Borosilicate Capillary Arrays for MCPs – Industrial Partnership w/Incom, Inc


Fused block ready for slicing



First block




Most recent block




- Multifiber stacking
- Triple point gaps
- Pore crushing at multifiber boundaries

- Triple points mostly eliminated
- Minimal boundary pore distortion



**Capillary array quality dramatically improved during last 2.5 years**






# Industrial Microchannel Plate Fabrication


Glass is gravity-fed via cylindrical furnace

Glass is typically lead glass tube with solid soft glass core

Chemical processing to remove soft core glass



Graphic Credit: B. Laprade & R. Starcher, Burle (2001)





Before sealing in tube, plate must be subjected to prolonged exposure to electrons at low voltage to outgas  $H_2$  and other material

# Pore Activation via Atomic Layer Deposition (ALD)


## Example:

- OH on surface provide reaction sites
  - Trimethyl aluminum reacts liberating methane, forms  $\text{Al}_2\text{O}_3$  layer. Leaves methyl group inhibiting further reaction on surface
  - Exposure to  $\text{H}_2\text{O}$  removes methyl group. Leaves OH sites for next reaction
- Leaves OH sites for next reaction






# Materials Characterization




Secondary Emissive Materials characterized with Low Energy Electron Diffraction (LEED)



# MCP Testing at Argonne and SSL – Facilities

Argonne 33mm & 8" Test Chambers  
with UV fs-pulse laser



SSL 33mm Test Chambers





Phosphor detector on left  
imaged with camera

Cross-strip delay line on right  
for gain mapping

SSL 8" MCP Test  
Detector Vacuum System


MCP on stripline  
anode ready for  
insertion into 8"  
chamber






# Noise Characterization

MgO SEE Layer



3000 sec background,  $0.0845 \text{ events cm}^{-2} \text{ sec}^{-1}$  at  $7 \times 10^6$  gain, 1025v bias on each MCP. Get same behavior for most of the current  $20\mu\text{m}$  MCPs



Post-bake –2000 sec  
 $\sim 0.1 \text{ events cm}^{-2} \text{ sec}^{-1}$





# 8" Photocathode Development – SSL/Berkeley

Na<sub>2</sub>KSb Photocathode Chosen for

- Resistivity
- Noise
- Temperature robustness
- Uniformity



**8" Photocathodes successfully produced at SSL**

- Cathodes in 8" test chamber with QE~25%
- Uniformity and stability meet MCP tube needs
- Ready to transfer techniques from 8" test ch. to large tube processing station.



graphics: Ossy Siegmund & Jason McPhate, SSL

Basic process is a co-evap technique. We get an enhancement of the QE after cool-down. The QE has remained stable over the 2 months since deposition.







#3A photocathode uniformity





# InGaN Photocathode Development – Washington University




# PSEC4 Performance


## Digitized Waveforms

Input: 800MHz, 300 mV<sub>pp</sub> sine

Sampling rate : 10 GSa/s



Sampling rate : 13.3 GSa/s



- Only simple pedestal correction to data
- As the sampling rate-to-input frequency ratio decreases, the need for time-base calibration becomes more apparent (depending on necessary timing resolution)



# Summary of Accomplishments 2009-2012

- ☑ Developed large area capillary arrays (20 $\mu$ m pore, L/D=60) for MCP substrate
  - Functionalized MCPs via separate Atomic Layer Deposition resistive and secondary emissive coatings
    - ☑ Demonstrated high gain ( $> 10^7$ ) with little aging
      - Success recognized with R&D100 award 2012
- ☑ Characterization of SEE materials within Argonne MSD
- ☑ Established MCP test facilities at Argonne and SSL/UC–Berkeley
- ☑ Developed detector-to-computer DAQ based on PSEC4 ASIC with 1.6GHz BW, 10–15 GSa/s
  - Timing resolution: 6ps differential, 63ps single pe
- ☑ 8" photocathodes (SSL) with QE~25% @ 350nm with good uniformity & stability
  - Established photocathode lab at Argonne and made first 4"&7" photocathodes
- ☑ Demonstrated signals from o-ring sealed all-glass economical tile at Argonne
  - Process tank for 8" ceramic tube at SSL ready for commissioning
- ➡ Completing ceramic body braze at SSL and on-track for working sealed tube in Fall 2012
- ☑ Development of 4×3 tile SuperModule tray with complete readout chain

- ☑ Original Proposal Milestone
- ➡ Milestone yet to be achieved